

Ghost Suppressor Install Instructions

An Alignment Tool is recommended for proper alignment
Inside your box:

Scan QR Code for
Video Instructions

Ghost Suppressor (fully assembled and ready to install)



Figure 1: Fenix Ghost Suppressor



The Fenix Ghost Suppressor will be fully assembled and ready to install on your Fenix Phantom Muzzle Brake (Figure 2). A Fenix Phantom Muzzle Brake is *required* to use The Fenix Ghost Suppressor.



Figure 2: Fenix Phantom Muzzle Brake ready to install The Fenix Ghost Suppressor.

To install:

1. Slide The Ghost Suppressor over The Phantom Muzzle Brake.



2. Twist The Ghost Suppressor turn clockwise until The Ghost Suppressor slides into place.



3. Tighten the Lock Jaw clockwise until it is tight. Do not overtighten.



Suppressor May loosen over time Retighten if it does